Downhill

Purlin Strut (When required)

Purlin

Purlin

Frame Rafter

Field Notch Sheeting Angle RA1 at Shop Welded Purlin Clips when Offset is 4"

Offset
4" (w/8" Girts)
5" (w/10" Girts)
6" (w/12" Girts)

Flange Brace, may be one or both sides of Rafter. See "Frame Cross Section" for requirements.

Shop Welded Clip

(2) $\frac{1}{2}$"∅ Bolts with $\frac{1}{2}$" Washer WFH500 located slot side

Sheeting Angle RA1 Attach to each Purlin with (1) Fastener #1B $\frac{1}{4}$"-14 x 1$\frac{1}{4}$" DP3

Typical 1" Inset attachment, attach with (2) $\frac{1}{2}$"∅ Bolts to Shop Welded Clip (See "Transverse Partition Framing Elevation" for locations)

Sheeting Clip
CL207 or PC29_
(1) Fastener #12A
12-14 x 1" DP3
at each end

1" Inset Partition Column
(See "Transverse Partition Framing Elevation" for locations and Flange Brace requirements, if required)

Field Notch Partition Base Framing at Column

Partition Base Framing Standard Base Angle RA1 shown, may vary. (See "Transverse Partition Framing Elevation" for requirement.)

$\frac{1}{4}$"∅ Anchor (Min.)
60" o.c. (Max.)
Not by Bldg. Mfr.

Zee Girts shown, attachment similar for Cee or Zee Girt with outer flange toed up.